


PCD8544 Usage



CLK	---	pin11	---	GPIO0 (17)
Din	---	pin12	---	GPIO1 (18)
D/C	---	pin13	---	GPIO2 (27)
CS	---	pin15	---	GPIO3 (22)
RST	---	pin16	---	GPIO4 (23)



If you are a C user, please test and use PCD8544 LCD according to the following steps:

1, Install wiringPi

```
cd /home
```

```
git clone git://git.drogon.net/wiringPi
```

```
cd wiringPi
```

```
sudo ./build
```

2, `cp yourpath/cpu_show.tar.gz /home`

```
tar xvf cpu_show.tar.gz
```

3, Compile files

```
cd /home/cpu_show
```

```
sudo ./compile
```

4, Run the program

```
sudo ./cpushow
```

NOTE :

Due to the contrast of each LCD are different, if you found the content displayed too dark or too light, you need to modify the contrast variables of `pcd8544_rpi.c`, and then recompile and run to see the effect of changes !

```
vim pcd8544_rpi.c
```

Modify the line 52, **int contrast = 45;**

45 is the default contrast, if the character LCD display is too light, set this value increases, decreases if the character LCD display is too dark. Recommended stepping value is 5. After the changes are complete, re-compile the code, and then run.

If you are a Python user, please test PCD8544 LCD according to the following steps:

1, Download example code

```
git clone https://github.com/adafruit/Adafruit\_Nokia\_LCD.git
```

2, Configure the base environment

```
cd Adafruit_Nokia_LCD
sudo apt-get install python-dev
sudo python setup.py install
sudo apt-get install python-imaging
```

3, Modify example code

```
cd examples
```

Since our PCD8544 LCD display does not use the hardware SPI interface of Raspberry Pi, so we use software to simulate SPI so as to drive PCD8544. The example code is based on hardware SPI. As a result, we need to make a few modifications to example code to drive PCD8455 LCD.

```
vim image.py
```

The modified code is as follows:

```
30 # Raspberry Pi hardware SPI config:
31 # DC = 23
32 # RST = 24
33 # SPI_PORT = 0
34 # SPI_DEVICE = 0
35
36 # Raspberry Pi software SPI config:
37 SCLK = 17
38 DIN = 18
39 DC = 27
40 RST = 23
41 CS = 22
42
43 # Beaglebone Black hardware SPI config:
44 # DC = 'P9_15'
45 # RST = 'P9_12'
46 # SPI_PORT = 1
47 # SPI_DEVICE = 0
48
49 # Beaglebone Black software SPI config:
50 # DC = 'P9_15'
51 # RST = 'P9_12'
52 # SCLK = 'PB_7'
53 # DIN = 'PB_9'
54 # CS = 'PB_11'
55
56
57 # Hardware SPI usage:
58 # disp = LCD.PCD8544(DC, RST, spi=SPI.SpiDev(SPI_PORT, SPI_DEVICE, max_speed_hz=4000000))
59
60 # Software SPI usage (defaults to bit-bang SPI interface):
61 disp = LCD.PCD8544(DC, RST, SCLK, DIN, CS)
62
```

4, Run the Python program just modified

```
sudo python image.py
```

Press Enter, you should see a cat displayed on PCD8544 LCD.

Also you can modify these two files of animate.py and shapes.py exactly in the same

way as image.py.Run and check the result.