


EC1204B V1.2 Key Functions of operation


Ver. 02
2015. 2. 23

Time Setting Operation:


Default: year、date、time、temperature
display rotation



Functions Setting:



Change the LED display:



DS1302 clock circuit is not working properly:

Power on



DS18B20 clock circuit is not working properly:

Power on



Functional specifications:

1、Hourly Chime:

Open Hourly Chime function, 8:00 to 22:00, the buzzer will ring every hour.

2、Clock Alarm:

open the alarm function , the buzzer will ring at the specified time, press any button to stop the ringing.

3、Temperature alarm:

Lower than the specified minimum temperature or higher than the specified maximum temperature, the buzzer will sound and lights flashing.